


onset®

**Using S-FS-TRMSA-D with U30-GSM**

If using the S-FS-TRMSA-D with a U30-GSM, the S-FS-TRMSA-D should be located approximately 1 meter (3 ft) from the U30 in order to avoid interference from the U30's GSM radio.

Use Smart Sensor extension cable Onset part # S-EXT-M002.



onset®

**Using S-FS-TRMSA-D with U30-GSM**

If using the S-FS-TRMSA-D with a U30-GSM, the S-FS-TRMSA-D should be located approximately 1 meter (3 ft) from the U30 in order to avoid interference from the U30's GSM radio.

Use Smart Sensor extension cable Onset part # S-EXT-M002.

