

Minol Pulse Output Water Flowmeter Connection Instructions

For use with HOBO® H21, H22, U30, UX90, UX120, and RX3000 series data loggers

Applies to this Minol Flowmeter

Onset Part No.	Output	Flow Rate (GPM)			Max. Pressure	Max. Temp.	Minol Part No.
		Min.	Cont.	Max.			
T-MINOL-130-NL	Pulses representing 1 US gal/pulse	0.25	11.0	22.0	150 psi	90°C (194°F)	Minomess 130

This document provides instructions on connecting the Minol Pulse Output Water Flowmeter listed above to HOBO H21, H22, U30, UX90, UX120, and RX3000 series data loggers.

Required


- Minol Pulse Output Water Flowmeter listed above
- HOBO H21, H22, U30, UX90, UX120, or RX3000 series data logger
- Pulse input adapter S-UCD-M00x for H21, H22, U30, and RX3000 series or RXW-UCD-xxx for RX3000 stations
- 22 AWG twisted pair wire (customer supplied) for UX120 series
- Adapter cable CABLE-2.5-STEREO for UX90 series
- HOBOWare® software, version 2.2.1 or higher for H21, H22, or U12; 2.4.0 or higher for U30 series; 3.2 or higher for UX120 series; 3.3 or higher for UX90 series
- HOBOLink for RX3000 station



Minol Pulse Output Water Flowmeter

Connecting the Pulse Output Flowmeter to the Logger


H21, H22, U30, or RX3000 Connection



Minol Pulse Output Water Flowmeter Connection Instructions

UX120 Connection


HOBO UX120 Series Data Logger



Customer-supplied
22 AWG twisted pair


Connect either the (+) or the ground (\pm) terminal from the UX120 terminal block to either of the two wires from the flowmeter (polarity not important) and then connect remaining two wires to each other. Use appropriate termination for connections.

Pulse Output Flowmeter



UX90-001/M Connection


HOBO UX90-001/M Data Logger



CABLE-2.5-STEREO

Connect either the black or the white CABLE-2.5-STEREO wire (red wire not used) to either of the two wires from the flowmeter (polarity not important) and then connect remaining two wires to each other. Use appropriate termination for connections.

Pulse Output Flowmeter



Data Interpretation:

Each pulse from the Minol flowmeter represents one US gallon. The data recorded in the logger will be the number of counts (pulses) per logging interval. For conversion to other units, the data must be exported from HOBO software (refer to the software documentation for details on exporting or sharing data).